



# ProNote 100/120

**Banknote Counter** 

Comfort und transparency you can count on





Make your cash flow.



ProNote 100/120 counts banknotes up to a speed of 1,500 Notes per minute and detects them if required for UV and MG security features. The clearly laid out LCD display and sophisticated menu system provide a clear overview of all important functions. A single button push is all that is needed to switch between available currencies, to switch between the count modes, to report with a detailed list of all counted notes (piece and value).

Further information on the display shows you how to handle the counting process in case of a certain error message.









MVB – Multi Value Balancing™ is a special function that overtakes for you the job of doing the addition when doing your cash balance.

#### **Currencies**

Value counting: EUR, USD, GBP

and three further self-definable currencies

#### **Count modes**

#### Value Balancing Mode:

Detection and value counting of pre-sorted banknotes

#### Piece Mode:

Detecting and piece counting

#### **Capacity and Speed**

Capacity hopper: 300 notes Capacity stacker: 200 notes

Add function: yes

Batching: variable 1:999 / preset

Counting speed: 800/1,200/1,500 notes per minute

### Safety Features detection in standard configuration

#### ProNote 100

UV

# ProNote 120

UV

MG

## **Certificates**

CE, RoHS

#### General data

Display type: LCD with 9-digits piece and

value display

Density setting: 8 levels

Document size:  $110 \times 50 \sim 175 \times 85 \text{ (mm)}$ 

Alarm type: visual and acoustic

double, chain, half, skew note Alarm system:

# **Technical data**

Dimensions: 287 x 243 x 248 mm (L x B x H)

Weight: 6,5 KG 60 W Power consumption:

AC 110-240 V / 50-60 Hz Power supply:

 $0^{\circ}$  C ~  $40^{\circ}$  C Ambient temperature: 40% ~ 90% Humidity:

#### **Interfaces**

- PC-connection via RS232
- external display via RS232

#### **Options**

- external display (cable included): 4 digits for piece number, 6 digits for value
- \* Power cable, RS-232 cable, fuse, cleaning cloth and brush as well as user manual included.







Last modified: 2012-05-25



